

Quick Guide

Wireless PC Card / Mini-PCI Card / USB Adapter

This Quick Installation Guide is intended for users who are familiar with Wireless LAN PC Card / Mini-PCI Card / USB Adapter driver installation for Windows 98/ME/2000/XP.

Installation for Windows 98/ME/2000/XP

During the installation, Windows may need to copy systems files from the Windows installation diskette or CD-ROM. Therefore you may need a copy of the Windows installation diskette or CD-ROM at hand before installing the drivers. On Win98/ME operating systems the necessary installation files are usually archived on the hard disk in the C:\WINDOWS\OPTIONS\CABS directory.

Run Setup from the Installation CD

1. Turn on the computer.
2. Make sure that there isn't any Wireless LAN PC Card / Mini-PCI Card / USB Adapter inserted.
3. Insert the **Installation CD** into your CD-ROM drive. The setup program should start automatically. If it does not start, you can run it manually by double clicking on the **setup.htm** file from CD-ROM drive.
4. Select the **Utility & Driver Install** hyperlink, and then click on the **Open** button.
5. The **Install Shield Wizard** will appear, click on the **Next** button. This will begin the installation process.
6. The installation process is ready to begin, click on the **Next** button.
7. Read the **Software License Agreement**, click on the **Yes** button. The installation process will then begin and copy the necessary files.
8. Click on the **Finish** button to complete the first part of the installation process.
9. Insert the PC card / Mini-PCI card / USB Adapter into the PCMCIA slot / PCI slot / USB port of your computer. Windows will then detect the device.

CAUTION: If you are using a PC/Mini-PCI card, align it properly, and gently insert it into the slot. Forcing a misaligned card into the slot can damage the card and the computer.

10. Select **Install the software automatically (Recommended)** radio button and then click on the **Next** button. Windows will then begin to copy the necessary files.
11. Click on the **Finish** button to complete the installation process.

Make sure that the network protocol parameters of your computer are set correctly. These include the IP address, subnet mask, gateway and DNS. If you aren't familiar with how to set the network protocol parameters, refer to the User's Manual in the Installation CD.

Quick Guide

Wireless PC Card / Mini-PCI Card / USB Adapter

View the User's Manual

The User's Manual includes a more detailed version of the installation process along with details on how to configure the client utility. Follow the steps below in order to view the User's Manual.

1. Insert the **Installation CD** into your CD-ROM drive. The setup program should start automatically. If it does not start, you can run it manually by double clicking on the **setup.htm** file from CD-ROM drive.
2. Select the **User's Manual** hyperlink for the PC Card, Mini-PCI Card or USB Adapter, and then click on the appropriate User's Manual to view the document.

Note: You must have Adobe Acrobat Reader installed on your computer in order to view the User's Manual.

Install Adobe Acrobat Reader 6.0

1. Insert the **Installation CD** into your CD-ROM drive. The setup program should start automatically. If it does not start, you can run it manually by double clicking on the **setup.htm** file from CD-ROM drive.
2. Select the **User's Manual** hyperlink for the PC Card, Mini-PCI Card or USB Adapter.
3. Select the **Install Acrobat Software** hyperlink, and then follow the installation steps to install Adobe Acrobat 6.0.